



Directions: Tape printable over desired area. Mark holes in wood using a punch and hammer. Drill 1/8" holes for standard pegs or 3/16" holes for large pegs. Sand and seal when finished.