



Directions: Tape printable over desired area. Use exacto blade to cut out template and score wood. Pencil in outer lines and remove printable. Use dremel or rotating tool to create 1/4" depressions in wood. Sand smooth and seal.